


INSPIRED

by **Bassett**[®]


Tradition Reinvented

Item# BP-YSXD60-W3
YESLER DESK
ASSEMBLY INSTRUCTIONS



IF PARTS ARE MISSING OR DAMAGED, DO NOT RETURN TO STORE

To order missing or replacement parts, contact us via e-mail parts@officestar.net, by Fax 1-909-930-5629, or toll free parts number 1-800-950-7262, Monday through Friday 8:00 a.m. - 5:00 p.m. Pacific Time.



WARNING

1. Do not use this product unless all screws and bolts are securely tightened.
2. Check that all screws and bolts are tight every three months or as needed.
3. Dispose of packing material properly. Do not use plastic cover as head covering. It may cause suffocation.
4. Do not use this product as a stepladder.
5. Use this product for its intended purpose only.
6. **Intended for residential use only.**


LIMITED WARRANTY

INSPIRED by Bassett® Warrants, to the original purchaser its products to be free from defects in material and workmanship for a period of 5 years. Defects and damage from misuse, abuse, negligence, alteration, accident, vandalism, rusting, acts of nature or any other event beyond the control of INSPIRED by Bassett® is not covered. The warranty does not cover cosmetic damage that may result from normal use. Liability for incidental or consequential damages is excluded. The user assumes all risk of injury resulting from use of this product. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.


To make a warranty claim, contact Customer Service, provide model number, sales receipt and description of the problem. It is the customer's responsibility to prepay freight on any components returned to the factory. INSPIRED by Bassett® will pay return freight on components covered under terms of warranty.

Contact us via e-mail parts@officestar.net, by Fax 1-909-930-5629, or toll free parts number 1-800-950-7262, Monday through Friday 8:00 a.m. - 5:00 p.m. Pacific Time.


PARTS LIST




(1) TOP PANEL (1 PC)




(2) LEFT PEDESTAL (1 PC)




(3) RIGHT PEDESTAL (1 PC)




(4) BACK PANEL (1 PC)




(5) UPPER RAIL (1 PC)



(6) LOWER RAIL (1 PC)



(7) KEYBOARD DRAWER (1 PC)



(8) ADJUSTABLE SHELF (1 PC)

HARDWARE LIST

NO	SKETCH	DESCRIPTION	SIZE	Q'TY
A		BOLT	ϕ1/4" X 1-1/2"	10 PCS+ 1 EXTRA
B		FLAT WASHER	ϕ1/4" X 16 mm	10 PCS+ 1 EXTRA
C		SPRING WASHER	ϕ1/4"	10 PCS+ 1 EXTRA
D		WRENCH	4 mm	1 PC
E		WOOD DOWEL	ϕ8 X 30 mm	16 PCS+ 2 EXTRA
F		SCREW	M4 X 19 mm	8 PCS+ 1 EXTRA
G		SHELF SUPPORT		4 PCS+ 1 EXTRA


NOTE: Phillips screwdriver also needed for assembly (not provided).

THANK YOU for purchasing this quality product. Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment. Identify and count all parts and compare with the parts and hardware lists.

Contact us via e-mail parts@officestar.net, by Fax 1-909-930-5629, or toll free parts number 1-800-950-7262, Monday through Friday 8:00 a.m. - 5:00 p.m. Pacific Time.


STEP 1:

Insert two Wood Dowels (E) into each end of Upper Rail (5) and Lower Rail (6). Attach Upper Rail (5) and Lower Rail (6) between Left Pedestal (2) and Right Pedestal (3). Secure Lower Rail (6) using four Flat Washers (B), four Spring Washers (C) and four Bolts (A). **DO NOT FULLY TIGHTEN BOLTS.** Secure Back Panel (4) between Left Pedestal (2) and Right Pedestal (3) using six Flat Washers (B), six Spring Washers (C) and six Bolts (A). **FULLY TIGHTEN ALL BOLTS (A) USING WRENCH (D).**




STEP 2:

Insert eight Wood Dowels (E) into top of assembly. Attach Top Panel (1) and secure to assembly using eight Screws (F). **FULLY TIGHTEN ALL SCREWS (F) USING PHILLIPS SCREWDRIVER (not provided).**




STEP 3:


Carefully Slide Keyboard Drawer (7) into desk.



STEP 4:

Insert four Shelf Supports (G) into desk and carefully place Adjustable Shelf (8) onto Shelf Supports (G).





FURNITURE CARE:

- Dust with a soft cloth following the grain pattern of the wood.
- Dust often to remove the everyday abrasive particles from the wood surfaces.
- Before dusting, moisten cloth lightly with a spray product.
- Wood finishes also benefit from an occasional polishing.

Contact us via e-mail parts@officestar.net, by Fax 1-909-930-5629, or toll free parts number 1-800-950-7262, Monday through Friday 8:00 a.m. - 5:00 p.m. Pacific Time.